

Dørtryk/ LEDNING

Bell push/ WIRE

Ringeknapp/Samtaleknapp/Ovi-painike




DK

2 ÅRS GARANTI

Tillykke med Deres nye dørtryk.
I denne brugsanvisning beskrives produktet, og vi anbefaler Dem at læse denne grundigt igennem, så korrekt anvendelse sikres.

PAKKEN INDEHOLDER:

- Dørtryk (sender) til anbringelse ved døren
- Fittings



IBRUGTAGEN:

- Fjern fronten af trykket og placer trykket på det ønskede sted.
- Marker med en blyant eller lign. de 2 hullers placering.
- Bor forsigtigt 2 huller til montering af trykket
- Bor desuden et hul i dørkarmen til trykkets ledning
- Før ledningen gennem hullet
- Forbind ledningen til de 2 skrueterminaler på bagsiden af trykket
- Monter trykket med de medfølgende skruer
- Monter fronten igen

Vigtigt: Anbring, så vidt muligt, dørtrykket således at det ikke udsættes for direkte vand og sollys.

GODKENDELSER:

CE

Opfylder R & TTE standard og gældende lovkrav



BORTSKAFFELSE:

Bør ikke bortskaffes med dagrenovation, men afleveres til genbrug. Kontakt din lokale genbrugsstation og følg deres anvisning.

* Der ydes 2 års garanti mod fabriktions- og funktionsfejl, regnet fra købsdato på produktet.

Ensonordic er udviklet af L-Team, som har mere end 25 års erfaring med el-produkter til det danske marked. Ensonordic-serien omfatter dørklokker, sensorer, røgalarmer, stikkontakter og andre komfort og sikkerhedsprodukter.

Se mere på www.ensonordic.com


UK

2 YEAR WARRANTY

Congratulations with your new Bell Push. This instruction manual explains the product and we advise you to read this carefully so that proper use is ensured. It is important to install this product in accordance with the fitting instructions below. Failure to do so may render your guarantee void. The instruction manual should be kept as long as the Bell Push is in use.

CONTENTS:

- Push Bell
- Fittings



FITTING INSTRUCTIONS:

- Remove the front cover of Bell Push
- Drill a hole in the door jam and lead the wire through the hole
- Connect the wire to connetcors on the back of the Bell Push
- Mount the Bell Push on the door jam with the screws included.
- Snap the front cover back on.

APPROVALS:

CE

R & TTE standard



RECYCLING:

Do not discard the unit with household waste, but in compliance with currantly enforced regulations.

In compliance with the Directive 2002/96/CE relative to waste from electrical and electronic equipment (WEEE) this product must be recycled.

For more information - www.ensonordic.com